## Talos Vulnerability Report

TALOS-2021-1253

## IOBit Advanced SystemCare Ultimate exposed IOCTL 0x9c406144 vulnerability

JULY 7, 2021

CVE NUMBER

CVE-2021-21786

Summary

A privilege escalation vulnerability exists in the IOCTL 0x9c406144 handling of IOBit Advanced SystemCare Ultimate 14.2.0.220. A specially crafted I/O request packet (IRP) can lead to increased privileges. An attacker can send a malicious IRP to trigger this vulnerability.

Tested Versions

IOBit Advanced SystemCare Ultimate 14.2.0.220

Product URLs

https://www.iobit.com/

CVSSv3 Score

8.8 - CVSS:3.0/AV:L/AC:L/PR:L/UI:N/S:C/C:H/I:H/A:H

CWE

CWE-782 - Exposed IOCTL with Insufficient Access Control

Details

IOBit Advanced SystemCare Ultimate provides a solution for keeping track of running services, processes that are using a large amount of memory, software updates, and the ability to update drivers to latest versions.

Advanced SystemCare also provides a monitoring driver to help facilitate its tasks. This driver creates \Device\IOBIT\_WinRing0\_1\_3\_0 which is readable and writable to everyone. The driver also provides a callback for handling IRP\_MJ\_DEVICE\_CONTROL requests to the driver.

The driver used in this analysis is below:

Monitor\_win10\_x64.sys e4a7da2cf59a4a21fc42b611df1d59cae75051925a7ddf42bf216cc1a026eadb

During IOCTL 0x9c406144, unprivileged user controlled data is passed to the HalGetBusDataByOffset function. This data is not constrained, giving the unprivileged user the ability to change I/O device configuration and device specific registers. The modification of this sensitive data can lead to the unprivileged user elevating their privileges.

Timeline

2021-02-17 - Initial contact

2021-02-23 - Vendor disclosure

2021-03-10 - Follow up with vendor

2021-04-30 - 2nd follow up with vendor

2021-05-17 - 3rd follow up with vendor

2021-06-27 - Final follow up with vendor

2021-07-07 - Public release

CREDIT

Discovered by Cory Duplantis of Cisco Talos.

VULNERABILITY REPORTS PREVIOUS REPORT NEXT REPORT

TALOS-2021-1252 TALOS-2021-1254

© 2022 Cisco Systems, Inc. and/or its affiliates. All rights reserved. View our Privacy Policy.